

INSTALLATION INSTRUCTIONS

69RT-1212-FM SPILL CONTAINMENT

Read these installation instructions completely and carefully before installation. The Universal 69RT comes pre-assembled for easy installation.

Before installing the 69RT containment manhole, coat both the male and female threads with a non-hardening pipe dope that is compatible with the product to be contained.

Install the 69RT by threading onto the tank riser until it is hand tight.

To finish tightening the unit, place a pipe wrench on the bottom external hex and tighten.

The top edge should be positioned a minimum of 2" above the final grade level to provide adequate slope for drainage. (See API recommended practices 1615)

To raise the units height place the enclosed spacer under the containment ring tabs. Screw down on the bolt provided. These adjustments will allow up to 1½" of movement up or down. If more adjustment is needed, then a longer or shorter riser pipe must be used.

NOTE: Every unit should be tested for leaks before and after installation. Fill the unit completely with water. If the water level drops within one hour, then a leak exists. Check the drain valve for proper seating and re-test. If the unit continues to leak, then replace the entire unit with another and re-test. After the concrete has been poured, re-test the unit to make sure no damage occurred during installation.

The unit should be tested and inspected every 6 months or more frequently if you are a high volume user or if conditions warrant. Damaged or leaking units should be replaced immediately.

Proven Performance



UNIVERSAL VALVE CO., INC.

478 Schiller Street • Elizabeth, New Jersey 07206

e-mail: sales@universalvalve.com

visit us at: www.universalvalve.com

